


Model No.6270D CORDLESS DRIVER DRILL 10MM



Model No.6270D CORDLESS DRIVER DRILL 10MM

Item No.	Parts No.	Description	Interchangeability	Q'ty	New/Old	Note1	Note2
001	125102-2	SPEED CHANGE LEVER ASS'Y		1			
002	183794-3	HOUSING SET		1	*		
D10		INC. 14,15					
002-1	183823-2	HOUSING SET	<	1			
D10		INC. 15					
003	860440-2	NAME PLATE 6270D		1	*		
003-1	860440-2	NAME PLATE 6270D	<	1			
004	266130-9	TAPPING SCREW BIND PT 3X16		9			
005	232182-2	LEAF SPRING		1			
006	417283-9	F/R CHANGE LEVER		1			
007	650556-9	SWITCH C3NA-1-M1		1			
008	643909-9	BATTERY HOLDER		1			
009	251468-5	- FLAT HEAD SCREW M6X22		1			
010	763185-0	KEYLESS DRILL CHUCK 10		1	*		
010-1	763185-0	KEYLESS DRILL CHUCK 10	<	1			
011	125237-9	GEAR ASS'Y		1			
012	629817-8	DC MOTOR		1			
013	911003-8	PAN HEAD SCREW M3X6		2			
014	819001-5	MAKITA LABEL		1	*		
015	183794-3	HOUSING SET		1	*		
D10		INC. 2,14					
015-1	183823-2	HOUSING SET	<	1			
D10		INC. 2					
A01	414938-7	BATTERY COVER		2			
A02	***DC1414	DC1414 BATTERY CHARGER		1			
A03	193100-4	BATTERY 1234 SET		2	*		
A03-1	193100-4	BATTERY 1234 SET	O	2			
A04	784636-0	+ - BIT 2-65		1			
A05	824635-1	PLASTIC CARRYING CASE		1			
C10	186347-7	SLIDE LATCH SET		1			
C20	819143-5	MAKITA LABEL		1			
A03	784636-0	+ - BIT 2-65		1			
A04	824635-1	PLASTIC CARRYING CASE		1	*		
C10	186347-7	SLIDE LATCH SET		1	*		
C20	819143-5	MAKITA LABEL		1	*		
A04-1	824652-1	PLASTIC CARRYING CASE	<	1			
C10	186347-7	SLIDE LATCH SET		1			
C20	819143-5	MAKITA LABEL		1			
A05	193981-6	BATTERY PA12 SET		2			
A04	824652-1	PLASTIC CARRYING CASE		1			
A03	192597-4	BATTERY 1222 SET		2			
A04	824581-8	PLASTIC CARRYING CASE		1			
C10	417059-4	LATCH		2			
A05	192749-7	ML120 RECHARGEABLE FLASHLIGHT		1	*		
A06	345261-8	HOOK PLATE		2			
A07	417926-3	STRAP G0970200500		1			
A08	193981-6	BATTERY PA12 SET		2			

A04	193994-7	TOOL CHEST		1			
A08	193100-4	BATTERY 1234 SET		2	*		
A08-1	193100-4	BATTERY 1234 SET	O	2			

Please state Parts No. when your order.

Print Date 10/06/2023