


Model No.DJV142 CORDLESS JIG SAW



Model No.DJV142 CORDLESS JIG SAW

Item	Parts No.	Description	I/C	Qty	New/Old	Opt. 1	Opt. 2	Note
001	187706-8	HOUSING SET		1				
C10	263005-3	RUBBER PIN 6		2				
D10		INC. 4						
002	265995-6	TAPPING SCREW 4X18		9				
003	814V53-3	DJV142 NAME PLATE		1				
004	187706-8	HOUSING SET		1				
C10	263005-3	RUBBER PIN 6		2				
D10		INC. 1						
005	142303-7	SWITCH PLATE COMPLETE		1				
006	650251-1	SWITCH SGEL106C-4		1				
007	632B56-3	SWITCH UNIT		1				
008	266034-5	TAPPING SCREW CT 4X16		4				
009	142112-4	GEAR HOUSING COVER COMPLETE		1				
010	326302-9	SAFETY WIRE		1				
011	911104-2	PAN HEAD SCREW M4X6		1				
012	454483-0	TOOL OPENER		1				
013	265026-1	+ PAN HEAD SCREW M4		1				
014	231659-4	TORSION SPRING 6		1				
015	346687-7	LINEAR GUIDE		1				
016	232207-2	LEAF SPRING		1				
017	911111-5	PAN HEAD SCREW M4X10 WITH W		4				
018	256117-9	PIN 4		1				
019	214031-5	PLANE BEARING 4		1				
020	961017-7	STOP RING E-3		1				
021	310548-7	SLIDER		1	*			
021-1	310837-0	SLIDER	<	1				
022	268090-1	PIN 4		1				
023	442195-7	GASKET		1				
024	267854-0	CAP WASHER 8		1				
025	421815-6	DUST SEAL 8		1				
026	267854-0	CAP WASHER 8		1				
027	424569-4	DUST COVER		1				
028	962063-3	RETAINING RING R-13		1				
029	165724-6	ROD		1				
030	257347-5	RING 21		1				
031	233591-8	TORSION SPRING 10		1				
032	233314-4	COMPRESSION SPRING 4		1				
033	310485-5	LOCK PIN		1				
034	310547-9	BLADE HOLDER		1				
035	256528-8	PIN 2		1				
036	961002-0	RETAINING RING S-6		1				
037	253715-0	FLAT WASHER 6		1				
038A	212014-9	NEEDLE BEARING 407		1	*			
038B	212014-9	NEEDLE BEARING 407		1	*			

Please order the parts with part number.

Print Date 24/10/2023

Model No.DJV142 CORDLESS JIG SAW

Item	Parts No.	Description	I/C	Qty	New/Old	Opt. 1	Opt. 2	Note
038-1A	212092-9	NEEDLE BEARING 407	O	1				
038-1B	212092-9	NEEDLE BEARING 407	O	1				
038-1C	212092-9	NEEDLE BEARING 407		1				
038-1D	212092-9	NEEDLE BEARING 407		1				
038-1E	212092-9	NEEDLE BEARING 407		1				
038-1F	212092-9	NEEDLE BEARING 407		1				
038-1G	212092-9	NEEDLE BEARING 407		1				
039	142109-3	GEAR COMPLETE		1				
040	313260-8	BALANCE PLATE		1				
041	346688-5	PUSH PLATE		1				
042	253196-8	FLAT WASHER 6		1				
043	454484-8	SEAL PLATE		1				
044A	272244-4	LEVER 17		1	*			
044B	272244-4	LEVER 17		1	*			
044-1A	272280-0	LEVER 17	<	1				
044-1B	272280-0	LEVER 17	<	1				
044-1C	272280-0	LEVER 17		1				
044-1D	272280-0	LEVER 17		1				
044-1E	272280-0	LEVER 17		1				
044-1F	272280-0	LEVER 17		1				
044-1G	272280-0	LEVER 17		1				
045	233139-6	COMPRESSION SPRING 3		1				
046	286032-3	CAP 5		1				
047	268063-4	PIN 4		1				
048	142111-6	GEAR HOUSING COMPLETE		1				
049	961018-5	STOP RING E-5		1				
050	210059-1	BALL BEARING 6000DDW		1				
051	519329-8	ROTOR ASS'Y		1	*			
D10		INC. 50,52			*			
051-1	619821-5	ROTOR	O	1				
D10		INC. 50						
052	210022-4	BALL BEARING 626DDW		1	*			
053	266490-9	TAPPING SCREW PT 2X6		3	*			
053-1	265C47-1	TAPPING SCREW PT 2X6	O	3				
054	629997-0	STATOR		1				
055	620247-6	CONTROLLER		1	*			
055-1	620B22-2	CONTROLLER	<	1				
056	643875-0	TERMINAL		1				
057	252171-1	SQUARE NUT M5-8		1				
058	142110-8	RETAINER COMPLETE		1				
059	319016-7	BASE		1				
060	345237-5	CRANK PLATE		1				
061	922231-0	HEX. SOCKET HEAD BOLT M5X20		1				
062	232208-0	LEAF SPRING		1				
063	346685-1	BASE PLATE		1				

Please order the parts with part number.

Print Date 24/10/2023

Model No.DJV142 CORDLESS JIG SAW

Item	Parts No.	Description	I/C	Qty	New/Old	Opt. 1	Opt. 2	Note
064	265085-5	+ COUNTERSUNK HEAD SCREW M4X8		4				
065	135602-4	ROD ASS'Y		1				
D10		INC. 27-29,31-35						
A01	126331-0	DUST NOZZLE ASSEMBLY		1				
A02	415524-7	ANTI-SPLINTERING DEVICE		1				
A03	417852-6	COVER PLATE		1				
A04	A-85737	JIGSAW BLADE NO.B22		1				
A05	A-85628	JIGSAW BLADE NO.B10		1				
A06	A-85793	JIGSAW BLADE NO.BR13		1				
A07	783202-0	HEX. WRENCH 4		1				
A08A	821550-0	CONNECTOR PLASTIC CASE (TYPE2)		1				
C10	453974-8	LATCH		4				
A08B	821550-0	CONNECTOR PLASTIC CASE (TYPE2)		1				
C10	453974-8	LATCH		4				
A08C	821593-2	PLASTIC CARRYING CASE		1				
C10	162315-4	LATCH		2				
A08D	821550-0	CONNECTOR PLASTIC CASE (TYPE2)		1				
C10	453974-8	LATCH		4				
A08E	821550-0	CONNECTOR PLASTIC CASE (TYPE2)		1				
C10	453974-8	LATCH		4				
A08F	821550-0	CONNECTOR PLASTIC CASE (TYPE2)		1				
C10	453974-8	LATCH		4				
A08G	821550-0	CONNECTOR PLASTIC CASE (TYPE2)		1				
C10	453974-8	LATCH		4				
A09A	837639-4	INNER TRAY		1				
A09B	837639-4	INNER TRAY		1				
A09D	837639-4	INNER TRAY		1				
A09E	837639-4	INNER TRAY		1				
A09F	837639-4	INNER TRAY		1				
A09G	837639-4	INNER TRAY		1				
A10A	802D81-2	DJV142ZJ PLASTIC CASE LABEL		2				
A10B	802D87-0	DJV142RM1J PLASTIC CASE LABEL		2				
A10C	805D19-6	DJV142RME PLASTIC CASE LABEL		2				
A10D	802D89-6	DJV142RMJ PLASTIC CASE LABEL		2				
A10E	806B10-5	DJV142Y1J PLASTIC CASE LABEL		2				
A10F	809L87-9	DJV142RT1J PLASTIC CASE LABEL		2				
A10G	809M74-4	DJV142RTJ PLASTIC CASE LABEL		2				
A11A	802D80-4	DJV142ZJ INDICATION LABEL		1				
A11B	***DC18RC	DC18RC FAST CHARGER		1				
A11C	***DC18RC	DC18RC FAST CHARGER		1				

Please order the parts with part number.

Print Date 24/10/2023

Model No.DJV142 CORDLESS JIG SAW

Item	Parts No.	Description	I/C	Qty	New/Old	Opt. 1	Opt. 2	Note
A11D	***DC18RC	DC18RC FAST CHARGER		1				
A11F	***DC18RC	DC18RC FAST CHARGER		1				
A11G	***DC18RC	DC18RC FAST CHARGER		1				
A12B	196388-5	BATTERY BL1440 SET		1	*			
A12C	196388-5	BATTERY BL1440 SET		2	*			
A12D	196388-5	BATTERY BL1440 SET		2	*			
A12E	196875-4	BATTERY BL1415N SET		1	*			
A12-1B	196388-5	BATTERY BL1440 SET	O	1	*			
A12-1C	196388-5	BATTERY BL1440 SET	O	2	*			
A12-1D	196388-5	BATTERY BL1440 SET	O	2	*			
A12-1E	196875-4	BATTERY BL1415N SET	O	1	*			
A12-1F	197122-6	BATTERY BL1450 SET		1	*			
A12-1G	197122-6	BATTERY BL1450 SET		2	*			
A12-2B	196388-5	BATTERY BL1440 SET	O	1				
A12-2C	196388-5	BATTERY BL1440 SET	O	2				
A12-2D	196388-5	BATTERY BL1440 SET	O	2				
A12-2E	196875-4	BATTERY BL1415N SET	O	1				
A12-2F	197122-6	BATTERY BL1450 SET	O	1				
A12-2G	197122-6	BATTERY BL1450 SET	O	2				
A13B	802D86-2	DJV142RM1J INDICATION LABEL		1				
A13C	450128-8	BATTERY COVER		1				
A13D	450128-8	BATTERY COVER		1				
A13F	809L86-1	DJV142RT1J INDICATION LABEL		1				
A13G	450128-8	BATTERY COVER		1				
A14D	802D88-8	DJV142RMJ INDICATION LABEL		1				
A14E	806B09-0	DJV142Y1J INDICATION LABEL		1				
A14G	809M73-6	DJV142RTJ INDICATION LABEL		1				
F02	192516-0	GUIDE RAIL		1				
F03	192557-6	ANTI-SPLITTING DEVICE		1				
F04	193516-3	GUIDE RULE SET		1				
C10	165217-3	GUIDE RULE		1				
C20	271601-3	KNOB 20		1				
C30	323802-0	GUIDE PIN		1				
C40	922207-7	HEX. SOCKET HEAD BOLT M5X10		1				
F05-1	193517-1	GUIDE RAIL ADAPTER SET	O	1				
C11	265785-7	THUMB SCREW M5X10	<	1				
C20	347393-7	RULE BAR		1				
C30	417894-0	GUIDE RAIL ADAPTER		1				
F06	194367-7	GUIDE RAIL 3000 SET		1				
C10	413102-7	SEAT 3000		2				
C20	423360-7	POSITION SHEET 3000		1				
C30	423362-3	RUBBER SEAT 3000		2				
C40	819212-2	MAKITA LOGO LABEL		1				

Please order the parts with part number.

Print Date 24/10/2023

Model No.DJV142 CORDLESS JIG SAW

Item	Parts No.	Description	I/C	Qty	New/Old	Opt. 1	Opt. 2	Note
F07	194368-5	GUIDE RAIL 1400 SET		1				
C10	413101-9	SEAT 1400		2				
C20	423359-2	POSITION SHEET 1400		1				
C30	423361-5	RUBBER SEAT 1400		2				
C40	819212-2	MAKITA LOGO LABEL		1				
F08	194925-9	GUIDE RAIL 1900 SET		1				
C10	423386-9	POSITION SHEET 1900		1				
C20	423390-8	RUBBER SHEET 1900		2				
C30	451330-6	SHEET 1900		2				
C40	819212-2	MAKITA LOGO LABEL		1				
F10-2	197252-3	GUIDE RAIL ADAPTER SET	O	1				
F13-3	197622-6	BATTERY BL1430B SET(2PIECES)	O	1	*			
F14-3	197615-3	BATTERY BL1430B SET	O	1				
F15-3	197616-1	BATTERY BL1430B SET	O	1				
F16-2	196386-9	BATTERY BL1440 SET	O	1				
F18-2	196388-5	BATTERY BL1440 SET	O	1				
F19-2	196393-2	BATTERY BL1440 SET (2PIECES)	O	1				
F20	199140-0	GUIDE RAIL 1000 SET		1				
F21	199141-8	GUIDE RAIL 1500 SET		1				

Please order the parts with part number.

Print Date 24/10/2023